

INSTALLATION INSTRUCTIONS

WALL END STABILIZER BRACKET

STEP 1: Fit stabilizer bracket into siderail lances of uprite & attach to wall end with tek screw.

NOTE: Tek screw may be installed in either available hole in bracket.



WEDPOS must be used with a height-to-base-compliant-wall end (see Inst Instr 01-13) and Wall End must use Base Brackets.

