

WALLCASE END PANELS

With wallcase in final position and anchored, determine the required width and height of the end panels. First, make saw cut at the bottom so the profile lines up with bottom of base nose. Next, cut top and back of end panel to proper size. With end panel in final location, place three panel hooks into standards at the desired height and tap down into standard slots. Secure with #10 x 5/8" pan head sheet metal screws. Fasten bottom of end panel to bottom arm with two #10 x 5/8" pan head sheet metal screws. The screws are installed through the predrilled holes in the bottom arm and into the end panel.

